
E-bike Chainquard Installation Instructions

Published - Jul. 2016. ZSP016.v3 © Full Speed Ahead

Introduction




Warranty

Full Speed Ahead (FSA) warrants all FSA, Vision, Metropolis and RPM products to be free from defects in materials or workmanship for a period of two years after original purchase unless otherwise stated in the full warranty policy. The warranty is non-transferable and valid to the original purchaser of the product only. Any attempt to modify the product in any way such as drilling, grinding, and painting will void the warranty. For more information on warranty policy and instructions for completing a warranty claim, check out the Full Warranty Policy found at our website: http://www.fullspeedahead.com/techdoc

Specification

Item Number / Model Name E-Bike Left crank CK-745/IS, CK-632/IS, CK-310/IS, AL-8/IS, CK-720/IS

Item Number / Model Name Chainguard W1121 (for 18T \ 19T \ 20T), W1122 (for 15T \ 16T \ 17T), W1125 (for 15T \ 16T \ 17T), W1126 (for 15T \ 16T \ 17T), W1126 (for 18T \ 19T \ 20T), W1002 (for 15T \ 16T \ 17T), W1129,





2. Chainguard

3. MW549 Spacer



3. Ensure the chainquard is

* If the chainguard is not

snapped on to the crank it

may fall off while riding.

crank.




Identify the crank

Check the crank for necessary Ø 3.1mm alignment hole near the spindle insert.

* Not all ISIS crank is compatible to the chainquard.



1. Place the chainquard on the crank and ensure the chainguard's alignment pin and crank's alignment hole fit together during assembly.



The chainquard is wedged it'self well to the crank see detailed illustration as below.



WWW.FULLSPEEDAHEAD.COM

2. Press the chainguard to fit to the crankspindle insert.

Ensure the chainquard wedge in the crank.




* Press the chainguard as the arrow in the illustration.



4. Place the MW549 Spacer 3 onto motor axle 4 with smooth side facing the motor and the recessed side facing outwards. Install crank ① and chainguard 2 on to axle and tighten crank bolt 5 to 400-600 kgf.cm / 40-60 N.m / 355-530







à

A CAUTION

in.lbs.

The MW549 Spacer 3 is for adjusting clearance between chainquard and chain or chainquard is mounted too loose on crank ①.

The Spacer is not required when the clearance between chainguard and chain is correct, or the chainquard is securely snapped on to the crank.



Contact

If you have questions, please visit our web site technical section: http://www.fullspeedahead.com/contact or contact:

Full Speed Ahead, USA 12212 Cyrus Way Mukilteo, WA 98275-5702 Tel: 1_425_488_8653 Fax: 1_425_489_1082

Full Speed Ahead, Europe Via Del Lavoro, 56 20874 Busnago, Milan, Italy Tel: +39_039_688_5265 Fax: +39_039_682_3336

TH INDUSTRIES / FSA Asia NO.6, Wu-gong 8th Rd., Wufeng Dist., Taichung City 41353, Taiwan (R.O.C.) Tel: +886_4_2331_9134 Fax: +886_4_2331_9314

METROPOLIS